SIEMENS

Data sheet 3RV2411-0KA10



Circuit breaker size S00 for transformer protection A-release 0.9...1.25 A N-release 26 A screw terminal Standard switching capacity

product brand name	SIRIUS
product designation	Circuit breaker
design of the product	For transformer protection
product type designation	3RV2
General technical data	
size of the circuit-breaker	S00
size of contactor can be combined company-specific	S00, S0
product extension auxiliary switch	Yes
power loss [W] for rated value of the current	
 at AC in hot operating state 	7.25 W
 at AC in hot operating state per pole 	2.4 W
insulation voltage with degree of pollution 3 at AC rated value	690 V
surge voltage resistance rated value	6 kV
maximum permissible voltage for safe isolation in networks with grounded star point	
 between main and auxiliary circuit 	400 V
 between main and auxiliary circuit 	400 V
shock resistance acc. to IEC 60068-2-27	25g / 11 ms
mechanical service life (switching cycles)	
 of the main contacts typical 	100 000
 of auxiliary contacts typical 	100 000
electrical endurance (switching cycles) typical	100 000
reference code acc. to IEC 81346-2	Q
Substance Prohibitance (Date)	01.10.2009
Ambient conditions	
installation altitude at height above sea level maximum	2 000 m
ambient temperature	
during operation	-20 +60 °C
during storage	-50 +80 °C
during transport	-50 +80 °C
temperature compensation	-20 +60 °C
relative humidity during operation	10 95 %
Main circuit	
number of poles for main current circuit	3
adjustable current response value current of the current-dependent overload release	0.9 1.25 A
operating voltage	
rated value	690 V
rated value	20 690 V

 at AC-3 rated value maximum 	690 V
	50 60 Hz
operating frequency rated value operational current rated value	1.25 A
operational current rated value operational current	1.23 A
	4.05.4
at AC-3 at 400 V rated value	1.25 A
operating power	
• at AC-3	0.01111
— at 230 V rated value	0.2 kW
— at 400 V rated value	0.4 kW
— at 500 V rated value	0.4 kW
— at 690 V rated value	0.8 kW
operating frequency	45.40
at AC-3 maximum	15 1/h
Auxiliary circuit	
number of NC contacts for auxiliary contacts	0
number of NO contacts for auxiliary contacts	0
number of CO contacts for auxiliary contacts	0
Protective and monitoring functions	
product function	
 ground fault detection 	No
phase failure detection	Yes
trip class	CLASS 10
design of the overload release	thermal
breaking capacity operating short-circuit current (Ics) at AC	
at 240 V rated value	100 kA
at 400 V rated value	100 kA
at 500 V rated value	100 kA
at 690 V rated value	100 kA
breaking capacity maximum short-circuit current (Icu)	
at AC at 240 V rated value	100 kA
at AC at 400 V rated value	100 kA
at AC at 500 V rated value	100 kA
at AC at 690 V rated value	100 kA
response value current of instantaneous short-circuit trip	26 A
unit	
UL/CSA ratings	
full-load current (FLA) for 3-phase AC motor	
at 480 V rated value	1.25 A
at 600 V rated value	1.25 A
yielded mechanical performance [hp]	
• for 3-phase AC motor	
— at 460/480 V rated value	1 hp
— at 575/600 V rated value	0.5 hp
Short-circuit protection	
product function short circuit protection	Yes
design of the short-circuit trip	magnetic
design of the fuse link for IT network for short-circuit protection of the main circuit	
• at 500 V	gL/gG 16 A
• at 690 V	gL/gG 16 A
Installation/ mounting/ dimensions	
mounting position	any
fastening method	screw and snap-on mounting onto 35 mm standard mounting rail according to DIN EN 60715
height	97 mm
width	45 mm
depth	97 mm
required spacing	
• for grounded parts at 400 V	

 upwards at the side for live parts at 400 V downwards upwards at the side for grounded parts at 500 V downwards upwards upwards at the side for live parts at 500 V downwards at the side for live parts at 500 V downwards upwards at the side for grounded parts at 690 V downwards upwards at the side for grounded parts at 690 V downwards at the side for live parts at 690 V downwards at the side for live parts at 690 V downwards backwards backwards backwards 	0 mm mm 0 mm 0 mm 0 mm 0 mm mm mm
 — at the side ● for live parts at 400 V — downwards — upwards — at the side ● for grounded parts at 500 V — downwards — upwards — upwards — at the side ● for live parts at 500 V — downwards — at the side ● for grounded parts at 690 V — downwards — upwards — upwards — at the side 9 r 50 50 — at the side — forwards ● for live parts at 690 V — downwards — at the side — forwards — backwards — upwards — forwards — backwards — at the side — backwards — at the side — at the side — forwards Or Connections/ Terminals 	O mm
 for live parts at 400 V — downwards — upwards — at the side 9 r • for grounded parts at 500 V — downwards — upwards — at the side • for live parts at 500 V — downwards — at the side • for grounded parts at 690 V — downwards — upwards — upwards — backwards — at the side — forwards • for live parts at 690 V — downwards — at the side — forwards • for live parts at 690 V — downwards — at the side — packwards — upwards — forwards — to rewards — at the side — at the side — at the side — at the side — forwards — at the side — forwards — at the side — forwards — forwards O reconnections/ Terminals) mm) mm) mm) mm mm) mm) mm) mm)
— downwards 30 — upwards 30 — at the side 9 r • for grounded parts at 500 V 30 — upwards 30 — at the side 9 r • for live parts at 500 V 30 — downwards 30 — at the side 9 r • for grounded parts at 690 V 50 — downwards 50 — backwards 0 r — forwards 50 • for live parts at 690 V 50 — downwards 50 — upwards 50 — backwards 0 r — backwards 0 r — at the side 30 — forwards 0 r Connections/ Terminals	0 mm
— upwards — at the side • for grounded parts at 500 V — downwards — upwards — at the side • for live parts at 500 V — downwards — upwards — upwards — at the side • for grounded parts at 690 V — downwards — upwards — upwards — backwards — at the side — forwards • for live parts at 690 V — downwards — at the side — forwards • at the side — forwards • for live parts at 690 V — downwards — at the side — forwards — upwards — upwards — at the side — forwards — upwards — upwards — upwards — backwards — upwards — or the side — forwards — or	0 mm
- at the side • for grounded parts at 500 V - downwards - upwards - at the side • for live parts at 500 V - downwards - upwards - upwards - at the side • for grounded parts at 690 V - downwards - upwards - backwards - at the side - forwards • for live parts at 690 V - downwards - backwards - at the side - forwards • for live parts at 690 V - downwards - at the side - forwards - upwards - backwards - upwards - upwards - backwards - upwards - backwards - upwards - backwards - backwards - backwards - at the side - forwards - or	mm) mm) mm) mm) mm mm) mm mm
for grounded parts at 500 V — downwards — upwards — at the side • for live parts at 500 V — downwards — upwards — upwards — upwards — at the side • for grounded parts at 690 V — downwards — upwards — upwards — upwards — backwards — at the side — forwards — for live parts at 690 V — downwards • for live parts at 690 V — downwards — upwards — upwards — upwards — at the side — backwards — upwards — backwards — at the side — forwards — at the side — forwards — at the side — forwards — forwards) mm) mm) mm) mm) mm mm) mm mm) mm) mm) mm
— downwards 30 — upwards 30 — at the side 9 r • for live parts at 500 V 30 — downwards 30 — at the side 9 r • for grounded parts at 690 V 50 — downwards 50 — backwards 0 r — at the side 30 — for live parts at 690 V 50 — downwards 50 — upwards 50 — backwards 0 r — backwards 0 r — at the side 30 — forwards 0 r Connections/ Terminals) mm
 — upwards — at the side • for live parts at 500 V — downwards — upwards — upwards — at the side • for grounded parts at 690 V — downwards — upwards — upwards — backwards — at the side — forwards — for live parts at 690 V — downwards • for live parts at 690 V — downwards — upwards — upwards — at the side — backwards — upwards — upwards — at the side — backwards — at the side — forwards — at the side — forwards — forwards — connections/ Terminals) mm
— at the side • for live parts at 500 V — downwards — upwards — at the side • for grounded parts at 690 V — downwards — upwards — backwards — at the side — forwards • for live parts at 690 V — downwards • for live parts at 690 V — downwards — upwards — at the side — forwards • for live parts at 690 V — downwards — upwards — upwards — upwards — upwards — or downwards — upwards — or downwards — upwards — or downwards — or downwar	mm) mm) mm mm) mm) mm mm) mm mm
 for live parts at 500 V downwards upwards at the side for grounded parts at 690 V downwards upwards upwards backwards at the side for live parts at 690 V downwards upwards for live parts at 690 V downwards upwards at the side at the side at the side forwards Connections/ Terminals) mm) mm) mm) mm) mm) mm mm
— downwards 30 — at the side 9 r ● for grounded parts at 690 V 50 — downwards 50 — backwards 0 r — at the side 30 — for live parts at 690 V 50 — downwards 50 — upwards 50 — backwards 0 r — backwards 0 r — at the side 30 — forwards 0 r) mm mm) mm) mm mm) mm
— downwards 30 — at the side 9 r ● for grounded parts at 690 V 50 — downwards 50 — backwards 0 r — at the side 30 — for live parts at 690 V 50 — downwards 50 — upwards 50 — backwards 0 r — backwards 0 r — at the side 30 — forwards 0 r) mm mm) mm) mm mm) mm
— at the side	mm) mm mm) mm mm) mm
 — at the side for grounded parts at 690 V — downwards — upwards — backwards — at the side — forwards • for live parts at 690 V — downwards — upwards — upwards — backwards — at the side — at the side — forwards Connections/ Terminals) mm) mm mm) mm
for grounded parts at 690 V — downwards) mm) mm mm) mm
— downwards 50 — upwards 50 — backwards 0 r — at the side 30 — forwards 0 r • for live parts at 690 V 50 — downwards 50 — upwards 50 — backwards 0 r — at the side 30 — forwards 0 r) mm mm) mm
— upwards 50 — backwards 0 r — at the side 30 — forwards 0 r • for live parts at 690 V — downwards 50 — upwards 50 — backwards 0 r — at the side 30 — forwards 0 r Connections/ Terminals) mm mm) mm
— backwards — at the side — forwards • for live parts at 690 V — downwards — upwards — backwards — backwards — at the side — forwards Connections/ Terminals	mm) mm
 — at the side — forwards ● for live parts at 690 V — downwards — upwards — backwards — at the side — forwards Or Connections/ Terminals) mm
— forwards • for live parts at 690 V — downwards — upwards — backwards — at the side — forwards — forwards Connections/ Terminals	
● for live parts at 690 V — downwards 50 — upwards 50 — backwards 0 r — at the side 30 — forwards 0 r Connections/ Terminals	
— downwards 50 — upwards 50 — backwards 0 r — at the side 30 — forwards 0 r Connections/ Terminals	
 upwards backwards at the side forwards On the side of t) mm
— backwards 0 r — at the side 30 — forwards 0 r Connections/ Terminals) mm
— at the side 30 — forwards 0 r	
— forwards 0 r Connections/ Terminals	
Connections/ Terminals) mm
	mm
product component removable terminal for auxiliany	
and control circuit	
type of electrical connection	
• for main current circuit sc	rew-type terminals
arrangement of electrical connectors for main current circuit	op and bottom
type of connectable conductor cross-sections	
for main contacts	
— solid or stranded 2x	((0,75 2,5 mm²), 2x 4 mm²
— finely stranded with core end processing2x	x (0.5 1.5 mm²), 2x (0.75 2.5 mm²)
• at AWG cables for main contacts 2x	x (18 14), 2x 12
tightening torque	
	8 1.2 N·m
	ameter 5 to 6 mm
	ozidriv size 2
design of the thread of the connection screw	
• for main contacts	3
Safety related data	
B10 value	
	000
proportion of dangerous failures	
) %
) %
	0 /0
failure rate [FIT]) FIT
) FIT
·	20
	nger-safe, for vertical contact from the front
	andle
Certificates/ approvals	
General Product Approval	Declaration of Conformity





Confirmation







Declaration of Conformity

Test Certificates

Marine / Shipping

UK Declaration of Conformity

Special Test Certific-<u>ate</u>

Type Test Certificates/Test Report







Marine / Shipping







Confirmation

other



Railway

Vibration and Shock

Confirmation

Further information

Information- and Downloadcenter (Catalogs, Brochures,...)

https://www.siemens.com/ic10

Industry Mall (Online ordering system)

https://mall.industry.siemens.com/mall/en/en/Catalog/product?mlfb=3RV2411-0KA10

Cax online generator

http://support.automation.siemens.com/WW/CAXorder/default.aspx?lang=en&mlfb=3RV2411-0KA10

Service&Support (Manuals, Certificates, Characteristics, FAQs,...)

https://support.industry.siemens.com/cs/ww/en/ps/3RV2411-0KA10

Image database (product images, 2D dimension drawings, 3D models, device circuit diagrams, EPLAN macros, ...)


http://www.automation.siemens.com/bilddb/cax_de.aspx?mlfb=3RV2411-0KA10&lang=en


Characteristic: Tripping characteristics, I2t, Let-through current


https://support.industry.siemens.com/cs/ww/en/ps/3RV2411-0KA10/char


Further characteristics (e.g. electrical endurance, switching frequency)

http://www.automation.siemens.com/bilddb/index.aspx?view=Search&mlfb=3RV2411-0KA10&objecttype=14&gridview=view1









last modified: 1/27/2022 🖸